







## LAG-91121K

TEMP. & WATER PRESSURE  
REQUIREMENTS


Note: Above values are the recommended values for Getting Conventional Outputs.

## TECHNICAL DRAWING





HOW TO INSTALL (Basin Mixer W/O Pop up) 

## HOW TO INSTALL





## HOW TO OPERATE







Apply soft cotton cloth



Apply soft cotton cloth




**✗ DON'T**




**✗ DON'T**

Don't apply Scrub



Steps & Cleaning agents requirements for Aerator Cleaning.



Aerator

1 hour Dip



De-SCALE Water



Liquid Soap  
PH-5-7